


ITEM NO.	ORDERING NUMBER	DESCRIPTION	QTY.	NOT INCLUDED
1	ASS-KIN-GEN3	Kinova Adapter Gen 3 to ISO Assembly	1	
2	ACC-KIN-MOUNT	Standard mounting kit for Kinova Gen3 Adapter	1	
3	GEN3-KIN-ARM	Kinova Gen3 Industrial robotic arm	1	X

MOUNTING STEPS

- Connect the Kinova adapter to the Gen3 robotic arm using the flex cable (ACC-KIN-MOUNT).
- Properly place the adapter (ASS-KIN-GEN3) on the robotic arm, making sure to place the connector face on the opposite side from where the camera of the robot is located.
- Use the screws (ACC-KIN-MOUNT) to properly attach the adapter.

NOTES



Hagenholzstrasse 85, 8050, Zurich, Switzerland
Email: info@botasys.com
Website: www.botasys.com
©2022 BOTA Systems AG. All rights reserved.

PRODUCT DESCRIPTION			
Adapter Kit from Kinova Gen3			
ORDERING NUMBER	DRAWING NUMBER	MODEL REVISION	DRAWING REVISION
ACC-KIN-GEN3	ACC-KIN-GEN3	A	A
WEIGHT	250g	SCALE: 1:20	PAGE: 2 / 2

A3